

KSF-620R2 – Multiroom Kit Operating Instructions

Items supplied with this kit are:

				
Remote Control	Power Adaptor	IR Sensor	LNB Loop Cable	C-Connector

We recommend that you only use the supplied accessories with this kit. Alternate power adapters and accessories may not work as desired and could possibly harm the equipment.

Assembly Instructions

Step 1



Turn the receiver off and connect the loop cable as above. The LNB LOOP of Tuner 1 connects to LNB IN of Tuner 2. Tuner 1 LNB IN will normally have a connection to the dish and is not shown in this image.

Step 2



Ensure the second room is connected via RF out of the second tuner. The remote control will operate through this connector.

Step 3



Connect the C-Connector in the "Antenna IN" of the television and the RF cable into the C-Connector as shown above.

Step 4



Connect the IR Sensor and the power adaptor connectors to the C-Connector as shown above.

Step 5



Plug the Power Adaptor to the wall socket and turn the power on.

Step 6

Ensure that the IR Sensor is visible when you are operating the remote control.

Step 7

Turn on the receiver

Step 8

Turn on the TV in the second room. Tune your television to UHF channel 50. This is the default and can be changed later.

Disassembly Instructions

Before disassembly, **ensure the Power Adapter is turned off first**. You may then disassemble in the reverse sequence.